



Address: 205 Barnes Road, RD2
Ladbrooks, 7672
PO Box 9181
Christchurch, 8243
NEW ZEALAND

Telephone: +64 3 329 6896
Fax: +64 3 3296893
Email: info@aceeca.com

Module replacement instructions

1/. Back up any data or software you may have installed on the Meazura™ by performing a Hotsync® operation using the Palm Desktop software or use the Card backup utility to backup to your CF card if you have one.

2/. Power down the Meazura™ by following one of the three methods below. Note: All data will be lost on the SDRAM!

- *Method 1* - If you already have a ROM504 or later installed, execute the *Device Info* application. Tap the *title bar* or *drop down menu icon* to pull down the menu. Tap the *Power Down System* item, followed by *Yes, Proceed* to power down.
- *Method 2* - Turn off the Meazura via the *On/Off* button. Press and hold the *down arrow* button down. Now simultaneously press and hold the *On/Off* button down. The Meazura will turn on for approx. 8 seconds and then power down.
- *Method 3* - Physically remove the battery.

3/. Unscrew and carefully remove the standard module from your Meazura™ RDA or scanner, followed by carefully inserting the new module.

4/. Fasten the module using a pozi screwdriver (PZ1) with torque setting at 40cNm (if possible), if not, please gently tighten the screws on the module until hand tight. Be careful not to over tighten as this may crack the plastic housing.

5/. Once the module is in place, perform a hard reset:

1. Press and hold the Power and Backlight button together then release the Backlight button only
2. Release the Power button when the Palm Powered logo appears
3. Follow on-screen instructions

6/. Restore your data and application from the Compact Flash card or perform a Hotsync®